

Existing product	Seajet 031 Samurai Seajet 032 Professional Seajet 033 Shogun Seajet 034 Emperor	Seajet 038 Taisho Seajet 039 Platinum	Seajet 037 Coastal
Attiva Professional AFP	■	■	■
Attiva Drake	■	■	■
Attiva Giraglia	■	■	■
Awlgrip Awlstar Gold Label	■	■	■
Boero Corsaire 611	■	■	■
Boero Altura 619	■	■	■
Boero Scirocco 622	■	■	■
Boero Magellan 630	■	■	■
Boero Mistral 633	■	■	■
Boero Admiral 933	■	■	■
Boero Season 952	■	■	■
Coppercoat	■	■	■
Hempel Alu Safe	■	■	■
Hempel Broads	■	■	■
Hempel Classic	■	■	■
Hempel Cruising Performer	■	■	■
Hempel Dynamic	■	■	■
Hempel Glide Cruise	■	■	■
Hempel Globic	■	■	■
Hempel Hard Racing	■	■	■
Hempel Mille Standard	■	■	■
Hempel Mille NCT	■	■	■
Hempel Olympic	■	■	■
Hempel Silic One	■	■	■
Hempel Tiger Extra	■	■	■
International Micron 77/99	■	■	■
International Micron 350	■	■	■
International Uni-Pro 250	■	■	■
International VC17M	■	■	■
International Cruiser 250	■	■	■
International Ultra 300	■	■	■
International Boatguard 100	■	■	■
International Trilux	■	■	■
International VC Offshore	■	■	■
Jotun Mare Nostrum	■	■	■
Jotun Megayacht Imperial	■	■	■
Jotun Non Stop	■	■	■
Jotun Racing	■	■	■
Nautix A3	■	■	■
Nautix A3 T. Speed	■	■	■
Nautix A4	■	■	■
Nautix A4 T. Speed	■	■	■
Nautix Marin	■	■	■
Niemeyer	■	■	■
Plastimo Classic	■	■	■
Plastimo Performance	■	■	■
Plastimo Racing	■	■	■
Seajet 031 / 032 / 033 / 034	■	■	■
Seajet 037 Coastal	■	■	■
Seajet 038 Taisho	■	■	■
Seajet 039 Platinum	■	■	■
Seajet Speed Finish	■	■	■
Soromap AF2	■	■	■
Stoppani Stopmar	■	■	■
Stoppani Clipper	■	■	■
Stoppani Sibelius	■	■	■
Teflon Antifouling	■	■	■
Tin-Based Antifouling	■	■	■
Unknown Antifouling	■	■	■

■ - Apply antifouling after removing slime or fouling with high pressure fresh water, remove loose antifouling and spot repair with the recommended primer.

■ - As above but light wet-sanding of the existing antifouling is required, then rewash before painting.

■ - As above but apply a barrier coat of Seajet 011 Underwater Primer before applying the new coating.

■ - Remove the existing antifouling and apply the recommended primer system before applying antifouling.

**Don't take any risks! Remove existing antifouling in poor condition.**